



**Included Accessories:**

- 1 725-1 6-pin spacer
- 1 725-PA plastic thumbturn
- 1 Matching strike
- Lock mounting hardware

## Typical Installation

